

Dichrome – Gearshift Knob Installation

1. Locate the Master Insert, permanently mounted in the base of your Gearshift Knob.

Carefully thread the Slave Insert into the Master Insert, until finger-tight.



2. Thread the Jam Nut onto your vehicle's gearshift shaft.

Depending on your vehicle, you may have to leave some exposed threads below the Jam Nut.



3. Finger-tighten the Gearshift Knob onto your vehicle's gearshift shaft.

Leave space between the base of the Knob and the Jam Nut.



4. Position the Gearshift Knob as desired.

Now turn the Jam Nut counter-clockwise, moving it back up the gearshift shaft, until finger-tight against the base of the Knob.



5. Gently tighten the Jam Nut against the base of the Gearshift Knob until secure.

Enjoy!



Disclaimer & Guarantee: Under normal driving conditions your Dichrome Automotive Glass Accessories will last a lifetime. Using Dichrome Accessories in racing vehicles, for speed shifting, or for any other specialized non-typical purpose is not recommended and highly discouraged. Improper installation or misuse can result in severe bodily injury. If any cracking occurs, remove immediately and return to Dichrome for evaluation. All inserts are guaranteed to never pull out. If your Dichrome insert should ever pull out or fail we will repair or replace your accessory at our discretion. All accessories should be finger tightened, never forced. Cross threaded accessories due to improper installation will not be covered by this guarantee.